

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# Coleman 2000020966 Owner's Manual

[Shop genuine replacement parts for Coleman  
2000020966](#)



[Find Your Coleman Grill Parts - Select From 260 Models](#)

----- Manual continues below part list -----

## Available Replacement Parts for Coleman 2000020966

|                           |                                   |
|---------------------------|-----------------------------------|
| <a href="#">9941-1711</a> | FASCIA KIT REPAIR PART            |
| <a href="#">9941-1881</a> | FOOT PAD REPAIR PART              |
| <a href="#">9941-3311</a> | WATER PAN FOR COLEMAN             |
| <a href="#">9941-5461</a> | BURNER ASSEMBLY-RIGHT REPAIR PART |
| <a href="#">9941-5471</a> | BURNER ASSEMBLY LEFT REPAIR PART  |
| <a href="#">9941-5631</a> | SIDE TABLE ASSEMBLY REPAIR PART   |
| <a href="#">9942-3811</a> | SIDE HANDLE ASSEMBLY REPAIR PART  |
| <a href="#">9942-5851</a> | IGNITER/ELECTRODE                 |

## Replacement Parts 9941A Series Stove

- |   |            |   |
|---|------------|---|
| 1 | 9941-5021  | Lid and Handle Assembly (Black)           |
|   | 9941-5071  | Lid and Handle Assembly (Stainless Steel) |
|   | 9941-5081  | Lid and Handle Assembly (Blue)            |
| 2 | 9941-3311  | Water Pan                                 |
| 3 | 9941-5471  | Burner Assembly – left                    |
| 4 | 9941-5461  | Burner Assembly – right                   |
| 5 | 5010000743 | Regulator Assembly                        |
| 6 | 9942-5851  | Igniter/Electrode                         |
| 7 | 9942-3811  | Side Handle Assembly w/boots and screws   |
| 8 | 9941-1711  | Fascia Kit (includes igniter button)      |

