


# MODELS 4005LPE & 4005SLPE GRILL HEAD EXPANDED VIEW




## GRILL HEAD PARTS LIST

No.	Part Name	Part Number
1	Hood Knob	G1125350
2	Lockwasher	B1008919
3	1/4-20 X 1/2 Hex Head Screw	T1009088
4	SEAR GRID® Set (2 Pieces Per Set)	20172302
5	Hood with Nameplate	20174204
6	Briquettes (Box)	20172202
7	LA-VA-GRATE®	20172503
8	Burner Box Sub-Assembly	20174502
9	Burner, ROTIS-A-GRATE®	20175902
10	Burner, Right Hand "S" Style	G4263651
11	Burner, Left Hand "S" Style	G4263615
12	Hair Pin Clip	G1026609
13	Clevis Pin	20175601
14	Control Box	20174801
15	Control Knob	20173202
16	Ignitor Knob	20173101
17	Manifold Support, Upper, w/Gasket	20174901
18	Manifold Assembly, w/Gasket	20175802
19	Gas Valve	20175401
20	Gas Orifice, Main Burner	G1031095
21	LP Gas Regulator	G4364024
22	Gas Connector Hose	G1129203
23	Fill Plug Adaptor (Not Shown)	G1136142
24	Rotary Ignitor	20173001
25	Electrode & Collector Box Assembly	G4313758
25A	Main Burner Electrode	G1129990
25B	#8 X 5/16 Hex Washer Head Screw (SS)	B1008795
25C	#8 X 1/2 Hex Washer Head Screw (SS)	G1031157
25D	Collector Box	G4163670
25E	Collector Box Strap	G4163698
26	Glow Wire	G4313301
27	"U" Burner Support	20175501
28	"C" Burner Support	G4162359
29	5/16-18 Self Tapping Screw	G1031406
32	Cooking Rack	G4313794
33	Gas Orifice, Rotis Burner	G1026743
34	ROTIS-A-GRATE®	20176101
35	Left Hand Spit Rod Support	G4260574

## GRILL HEAD PARTS LIST

No.	Part Name	Part Number
36	Right Hand Spit Rod Support	G4260583
37	Spit Rod	20176202
38	Spit Motor	G0627006
39	Nut, Thread Covering Acorn	G1045080
40	Meat Hook Set (2 Per Set)	G4313696
41	ROTIS-A-GRATE® Burner Support	20176301
42	ROTIS-A-GRATE® Electrode	G1130004
43	SMOKE-IT-TRAY®	G4309147
44	Rotis Pan (Not Shown)	G4309129
45	#10 Acorn Nut	G1026547
46	#10 Truss Head Screw	G1026538
50	#10 X 1/2 Hex Washer Head Screw (SS)	G1026305
51	#10 X 5/8 Hex Washer Head Screw	B1008062
52	Angle, Supply Line Support	20176501
53	Electrode Bracket Screw	B1008571
54	1/8 Elbow	G1031111


# SIDE-ORDER COOKER® EXPANDED VIEW



## SIDE-ORDER COOKER® PARTS LIST

No.	Part Name	Part Number
1	Side-Order Cooker® Body	20172603
2	Burner	20172701
3	Trivet	G1136400
4	Pot Guard	G1136419
5	Rotary Ignitor	20172801
6	Knob, Ignitor	20173101
7	Gas Valve	G1827548
8	Knob, Gas Valve	20173201
9	Orifice	G1031095
10	Electrode	G1129990
11	Burner Securing Bracket	20173601
12	Flare Adaptor	G1045017
13	Hose	G1136482
14	Tee	G1045026
18	Snap Bushing	G1045044
19	Cover, Burner	20173801
20	Cover Retainer	20173901
21	Screw, 1/4-20 X 1/2 Hex Slotted Washer Head	T1009088
22	Screw, 8-32 X 3/8 Phillips Pan Head	20173501
24	Heat-Resistant Mitt (Not Shown)	G1136884
26	Flange Fitting	G1136768
27	Screw, #8 X 1/2 Phillips Head	G1026181
28	Screw, 9-32 X 5/16 Hex Slotted Washer Head	B1008704
29	Bracket, Valve Support	20173701
30	Lockwasher	B1008919

# GRILL CABINET EXPANDED VIEW



## CABINET ASSEMBLY PARTS LIST

No.	Part Name	Part Number
54	Top Frame	20179601
55	Bottom Shelf	20179701
56	Back Panel	20179801
57	Side Panel, Right Hand	20179901
58	Side Panel, Left Hand	20180001
59	Partition	20180101
60	Shield, Storage Compartment	20180201
61	Shield, Side Compartment	20180301
65	Bottom Door, Left Hand	20179301
66	Bottom Door, Right Hand	20179302
67	Side Door	20180401
68	Front Panel	20179202
69	Door Handle with Screws	G4312142
70	Plastic Bushing	G1026145
71	Door Hinge with Screws	G4312151
72	Center Post	20180501
73	Latch Plate	G4161476
74	Left Support for Side Cooker	20181001
75	Legs (Set of 4)	20180601
76	Right Support for Side Cooker	20181101
77	Caster Plug	G1125074
78	Swivel Caster, Locking Type	G1125065
79	Axle 1/2 Dia. X 29"	20180701
80	Hub Cap, 1/2"	G1125592
81	Wheel, 6" Dia.	G1127101
82	Tubing End Cap	G1026010
83	Handle Grip	G1125038
84	#10 X 5/8 Hex Washer Head Screw	G1045124
85	Lighter Hole Tube (Long)	20180901
86	Lighter Hole Tube (Short)	20180902
87	Chain Bottle Retaining	G1127125
88	Folding Side Shelf	G4312786
89	Support Rod, Shelf	G1125369
90	Support Bracket	G4161654
91	Bracket, Burner Box Support	20179505
92	Hickory Wood Chips (Not Shown)	G4312820
93	Mesquite Wood Chips (Not Shown)	G4312839