

1 Remove end of rating label located on your grill's back panel (see parts list to identify) and apply to your warranty card in box #5. If label cannot be removed, write the numbers on your warranty card.

NEVER Store a spare propane tank in a vehicle. NEVER fill the tank to the top. NEVER use a propane tank that has caused a fire or explosion. NEVER use a propane tank that has been damaged. NEVER use a propane tank that has been exposed to fire. NEVER use a propane tank that has been exposed to rain or snow. NEVER use a propane tank that has been exposed to extreme temperatures. NEVER use a propane tank that has been exposed to any other hazardous conditions.

NE JAMAIS remiser u propane sous le grill. **NE JAMAIS** remplir le réservoir de propane à ras bord. **NE JAMAIS** utiliser un réservoir de propane qui a causé un incendie ou une explosion. **NE JAMAIS** utiliser un réservoir de propane qui a été endommagé. **NE JAMAIS** utiliser un réservoir de propane qui a été exposé à la pluie ou à la neige. **NE JAMAIS** utiliser un réservoir de propane qui a été exposé à des températures extrêmes. **NE JAMAIS** utiliser un réservoir de propane qui a été exposé à toute autre condition dangereuse.

OUTDOOR GAS GRILL

Serial Number: 0000000000
Model Number: 0000000000

© 2010 The Coleman Co. Oklahoma City, OK

This label contains the model and serial number for your grill. You should also write this information on page 2 of your Use and Care Manual in the "Warranty Information" box.

2

1ST Unbolt legs to position shown, laying grill **ON ITS BACK**. Rest lower portion of panel on legs, aligning panel holes with leg holes.

2ND Attach panel and brace with four bolts and nuts. **BRACE ATTACHES TO RIGHT SIDE.**

NOTE: To prevent scratching, lay grill on packing material to assemble.

3

1ST Stand grill upside down and brace with four bolts and nuts.

2ND Flip back of grill, depress back of grill into leg assembly into right legs and wheel assembly (left facing) **IMPORTANT:** Align tabs with notches in legs.

4

1ST Position both ends of wire into holes on inside of left legs and right ends of wire angled upward. Insert ends of wire into holes on inside of left legs and rotate wire downward.

2ND Tank wire correctly installed.

3RD Wire angled upward.

4TH Wire angled upward.

5

1ST Place 45 briquets into back of grill. Arrange briquets as shown below.

2ND Position Chip Vaporiser Bar as shown supports at each end of grill bottom.

Briquet Placement

FRONT BACK

FRONT BACK

FRONT BACK

6

1ST Place lid onto grill bottom. Attach with two hinge pins.

2ND Insert handle into grill lid. Attach with two wing nuts.

3RD Be sure clips are attached to leg plate posts. Snap leg plate into grill fit.

You may have:

Hinge pin only OR Hinge pin

Qty. 2

Qty. 2

7

1ST Insert pivot wire of warming rack into grill lid. Flex leg wires to insert into grill bottom (see inset).

2ND Place cooking grate into grill bottom.

Back of warming rack pointing upward.

Pivot Wire

Leg Wire

8

1ST Install side shelves by sliding shelf tubes over ends of leg tubes. Press firmly so that holes are aligned. Secure with one push-fastener on each leg.

Qty. 4

9

1ST LP GAS TANK IS SUPPLIED EMPTY. Fill and leak-check tank before attaching to grill and regulator. See Use & Care Manual.

2ND Center base of tank in notches between wheels. Snap tank into grill bottom. Center section of tank wire should be inside of tank collar.

Regulator

Leg shelf not shown for clarity

Center section of tank wire should be inside of tank collar.

Center section of tank wire should be inside of tank collar.

Center section of tank wire should be inside of tank collar.

CAUTION

- Tank collar opening must face to front of cart once tank is attached.
- Failure to install tank correctly may allow gas flow to be restricted or blocked, resulting in the risk of fire.

Step 10 on reverse side.

See Use & Care Manual to perform "Burner Flame Check" and for important safety instructions before using.

4617216