



**Parts List - Model 403731913**

Part No.	Description	Part No.	Description	QTY
A-1	Assembly	01	Top Front/Back	1
B-1	Assembly	02	Side Support	2
C-1	Assembly	03	Leg Plate	2
D-1	Assembly	04	Support	2
E-1	Assembly	05	Support	2
F-1	Assembly	06	Support	2
G-1	Assembly	07	Support	2
H-1	Assembly	08	Support	2
I-1	Assembly	09	Support	2
J-1	Assembly	10	Support	2
K-1	Assembly	11	Support	2
L-1	Assembly	12	Support	2
M-1	Assembly	13	Support	2
N-1	Assembly	14	Support	2
O-1	Assembly	15	Support	2
P-1	Assembly	16	Support	2
Q-1	Assembly	17	Support	2
R-1	Assembly	18	Support	2
S-1	Assembly	19	Support	2
T-1	Assembly	20	Support	2
U-1	Assembly	21	Support	2
V-1	Assembly	22	Support	2



**QUICKSET™**  
 403731913  
 ASSEMBLY MANUAL

**THIS GRILL IS FOR OUTDOOR USE ONLY**

**CAUTION:** Read and follow all safety warnings, assembly instructions, and use instructions thoroughly before attempting to assemble and cook.

**INSTALLATION:** Read these instructions carefully.

**CONSUMER:** Read the manual for safe use.

**WARNING:** Failure to follow all manufacturer's instructions could result in serious personal injury and/or property damage.

**CAUTION:** Never use this grill unless it is properly assembled and used in accordance with the instructions provided in this manual.

**Char-Broil**  
 KEEPERS OF THE FLAME