

1

Parts to assemble:
2 Leg Assembly
1 Midshelf
1 Base
8 Carriage Bolt, 2"
8 Plastic Tee Knob

A. Place base on edge with tank hole to left.
B. Attach legs to base with bolts and tee knobs.
DO NOT FULLY TIGHTEN.
C. Insert midshelf into holes on insides of legs, long wires to left side. **Fully tighten bolts and tee knobs.**

Leg Assembly

Long midshelf wire to left side.

IMPORTANT! USE TOP HOLE

Base

Qty. 8

Qty. 8

NOTE: To prevent scratching, lay grill on packing material to assemble.

2

Parts to assemble:
2 Wheel Assembly
2 Hitch Pin
2 Leg Extender

A. Insert wheel assemblies into bottom holes on left legs.
B. Secure beneath base with hitch pins.
C. Push leg extenders into right legs.

Wheel/Hubcap Assembly

Completed assembly with hitch pin in axle bolt.

Leg Extender

Qty. 2

3

Parts to assemble:
1 Upper Front Panel
1 Lower Front Panel

A. Snap the upper and lower front panels together.
B. Insert the two pins on lower panel into holes in front of cart base.
C. Snap the upper panel over the midshelf wire.

NOTE: Rear view of cart. Wheels are to right side.

Upper Front Panel

Lower Front Panel

Upper panel snaps onto midshelf wire.

4

Parts to assemble:
1 Panel Support Wire
1 Condiment Wire

A. Insert panel wire through upper panel and into leg, then bend wire slightly to insert opposite end.
B. Hook the outer condiment wires into the top holes on front of upper panel, then slide remaining wires into panel holes below the condiment shelf.

Upper Panel Wire (Bend slightly to insert)

NOTE: front view of cart. Wheels are to left side.

Condiment Wire

NOTE: Rear view of cart. Wheels are to right side.

5

Parts to assemble:
1 Grill Bottom/Control Panel Assembly
2 Carriage Bolt, 1/4-20x1 1/4"
2 Carriage Bolt, #10-24x1 1/4"
2 Metal Wing Nut, 1/4-20
2 Plastic Tee Knob

A. Carefully place grill bottom/control panel assembly onto cart. Front of control panel should overlap top lip of upper front panel.
B. Insert 1/4-20 bolts through grill bottom and center hole in support bar. Secure with metal wing nuts.
C. Insert #10-24 bolts through control panel and front holes in support bar. Secure with plastic tee knobs.

1/4-20

#10-24

Support Bar Front Hole

Grill Bottom/Control Panel Assembly

Support Bar Center Hole

Qty. 2 (1/4-20)

Qty. 2 (#10-24)

Qty. 2 (1/4-20)

Qty. 2

NOTE: Front view of cart. Wheels are to left side.

6

Parts to assemble:
1 V-Bar

A. Place V-bar onto supports at each end of grill bottom.

V-Bar

7

Parts to assemble:
2 Side Shelf
8 Wing Screw
4 End Cap

A. Push an end cap into each leg.
B. Place side shelves onto legs and secure with four wing screws per shelf.

Side Shelf

End Cap

Qty. 8

8

Parts to assemble:
1 Grill Lid
1 Handle
1 Logo Plate/Heat Indicator
2 Metal Wing Nut
2 Hinge Pin
2 Hitch Pin

A. Attach lid to grill bottom with hinge and hitch pins.
B. Attach handle to lid with two metal wing nuts.
C. Snap logo plate/heat indicator into lid.

Handle

Logo Plate/Heat Indicator

Grill Lid (Lid style may vary)

Qty. 2

Qty. 2

Qty. 2

9

Parts to assemble:
1 SwingAway
1 Cooking Grate

A. Insert SwingAway pivot wires into holes in sides of grill lid.
B. Insert SwingAway leg wires into top holes in sides of grill bottom.
C. Place cooking grate onto grate rests in grill bottom.

Note: Wires at rear of SwingAways should point upward.

SwingAway

Pivot Wire

Leg Wire

Cooking Grate

10

Parts to assemble:
1 Tank Wire
1 Grease Clip

A. Insert ends of tank wire into slots on each side of tank hole in grill base. Lean tank wire toward midshelf.
B. Hang grease clip beneath grill bottom. To collect grease, hang an empty soup can (not included) from grease clip.

Tank Wire

Rear view of grill.

Grease clip hanging under grill bottom.

CAUTION

Failure to install can in clip will cause hot grease to drip from bottom of grill with risk of fire or property damage.

11

Parts to assemble:
1 LP Gas Tank (Not included.)

CAUTION

Tank collar opening must face to front of cart once tank is attached.

Failure to install tank correctly may allow gas hose to be damaged in operation, resulting in the risk of fire.

See Use & Care manual to perform the "Burner Flame Check" and for important safety instructions before using.

LP tank is sold separately. Fill and leak check before attaching to grill and regulator.

A. Place LP tank into hole in base with tank valve facing toward front of grill.
B. To secure LP tank, pull tank wire over the side of the tank, toward the tank collar.

Tank Collar

LP Tank (Sold Separately)

Pull tank wire over tank.

Rear view of grill.