


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Broil King 951-74 Owner's Manual

[Shop genuine replacement parts for Broil King 951-74](#)



[Find Your Broil King Grill Parts - Select From 1348 Models](#)

----- Manual continues below -----


Broil King

REDDI-BILT BARBECUES


ASSEMBLY MANUAL & PARTS LIST

MANUAL DE MONTAGE & LISTE DE PIÈCES


Broil King
CROWN 2
941-24
941-27





Broil King
CROWN 4
941-44
941-47




Broil King
REGAL 2
951-24
951-27




Broil King
REGAL 4
951-44
951-47



Broil King
REIGN 25
951-74
951-77



Broil King
SOVEREIGN 30
951-94
951-97




RETAIN FOR FUTURE REFERENCE

VEUILLEZ CONSERVER POUR REFERENCE ULTERIEURE

MANUFACTURED BY / FABRIQUES PAR LA

OMC ONWARD MULTI-CORP INC. 932 VICTORIA ST. N., KITCHENER, CANADA N2B 1W4



-168-
PARTS LIST/LISTE DES PIECES

	ITEM #	DESCRIPTION	DESCRIPTION	941-24	941-44	951-24	951-44	951-74	951-94
				941-27	941-47	951-27	951-47	951-77	951-97
1.	10909-T32	CASTING BOTTOM	FOND DU FOYER	1	1	•	•	•	•
	10909-T42	CASTING BOTTOM	FOND DU FOYER	•	•	1	1	1	1
2.	10473-T32	CASTING TOP	COUVERCLE DU GRIL	1	1	•	•	•	•
	10473-T42	CASTING TOP	COUVERCLE DU GRIL	1	•	1	1	1	1
3.	10081-BK32	NAMEPLATE	PLAQUE D'IDENTIFICATION	1	1	•	•	•	•
	10081-BK426	NAMEPLATE	PLAQUE D'IDENTIFICATION	•	•	1	1	•	•
	10081-BK422	NAMEPLATE	PLAQUE D'IDENTIFICATION	•	•	•	•	1	1
5.	S15156	HEAT INDICATOR	INDICATEUR DE CHALEUR	1	1	1	1	1	1
7.	S21233	HINGE CLIP	ATTACHE DE CHEVILLE	2	2	2	2	•	•
8.	10222-T32	GRATE	GRILL POUR BRIQUETTES	1	1	•	•	•	•
	10222-T42	GRATE	GRILL POUR BRIQUETTES	•	•	1	1	1	1
9.	10225-T326	GRID - CAST IRON	GRILLE	2	2	•	•	•	•
	10225-T426	GRID - CAST IRON	GRILLE	•	•	•	•	•	•
11.	10225-T327	GRID RETRACTABLE	GRILLE RETRACTABLE	•	•	2	2	2	2
	10225-T428	GRID RETRACTABLE	GRILLE RETRACTABLE	1	1	•	•	•	•
14.	10010-45	BRIQUETS - CERAMIC	BRIQUETTES - CERAMIQUE	1	1	•	•	•	•
	10010-55	BRIQUETS - CERAMIC	BRIQUETTES - CERAMIQUE	•	•	1	1	1	1
15.	10390-T401	BURNER ASSY	ENSEMBLE DE BRULEUR	1	1	•	•	•	•
	10390-T501	BURNER ASSY	ENSEMBLE DE BRULEUR	•	•	1	1	1	1
17.	10342-21	IGNITOR	ALLUMEUR	1	•	1	•	1	•
	10342-22	IGNITOR	ALLUMEUR	•	1	•	1	•	1
18.	S15504	ELECTRODE	ELECTRODE	1	1	1	1	1	1
21.	10440-K40	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	1	•	•	•	•	•
	10440-K41	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	1	•	•	•	•	•
	10440-K42	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	1	•	•	•	•
	10440-K43	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	1	•	•	•	•
	10440-K50	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	•	1	•	•	•
	10440-K51	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	•	1	•	•	•
	10440-K52	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	•	•	1	•	•
	10440-K53	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	•	•	1	•	•
	10440-K58	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	•	•	•	•	1
	10440-K59	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	•	•	•	•	1
	10440-K62	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	•	•	•	1	•
	10440-K63	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	•	•	•	1	•
21A.	S10125	HOSE - SIDE BURNER LP	TUYAU DU BRULEUR LATERAL PL	•	1	•	1	•	1
	S10126	HOSE - SIDE BURNER NG	TUYAU DE BRULEUR LATERAL GN	•	1	•	1	•	1
21B.	S10133	HOSE - REARBURNER LP	TUYAU DE BRULEUR ARRIERE PL	•	•	•	•	1	•
	S10139	HOSE - REARBURNER NG	TUYAU DE BRULEUR ARRIERE GN	•	•	•	•	1	•
	S10134	HOSE - REARBURNER LP	TUYAU DE BRULEUR ARRIERE PL	•	•	•	•	•	1
	S10140	HOSE - REARBURNER NG	TUYAU DE BRULEUR ARRIERE GN	•	•	•	•	•	1
22.	10114-20	HOSE & REGULATOR LP - QCC1	TUYAU ET REGULATEUR PL - QCC1	1	1	1	1	1	1
	10111-K47	HOSE NATURAL GAS	TUYAU (GAZ NATUREL)	1	1	1	1	1	1
23.	10472-K36	CONTROL KNOB	BOUTON DE CONTROLE	2	3	2	3	3	4
30.	10086-K401	DECO PLATE	PLAQUE DECORATIVE	1	•	•	•	•	•
	10086-K411	DECO PLATE	PLAQUE DECORATIVE	•	1	•	•	•	•
	10086-K501	DECO PLATE	PLAQUE DECORATIVE	•	•	1	•	•	•
	10086-K511	DECO PLATE	PLAQUE DECORATIVE	•	•	•	1	•	•
	10086-K521	DECO PLATE	PLAQUE DECORATIVE	•	•	•	•	•	1
	10086-K531	DECO PLATE	PLAQUE DECORATIVE	•	•	•	•	1	•
31	10184-K401	CONTROL COVER	PANNEAU DE CONTROLE	1	1	•	•	•	•
	10184-K501	CONTROL COVER	PANNEAU DE CONTROLE	•	•	1	1	1	1
32.	10338-K561	POST LEG	PIEDS	2	2	2	2	•	•
33.	10338-K571	POST WHEEL	PIEDS DE ROUE	2	2	2	2	4	4
35.	10184-K561	SUPPORT - CASTING - LEFT	SUPPORT GAUCHE DU FOYER	1	1	1	1	1	1
#	10184-K571	SUPPORT - CASTING - RIGHT	SUPPORT DROIT DU FOYER	1	1	1	1	1	1
	10184-K581	SUPPORT - SIDE SHELF - LEFT	SUPPORT TABLETTE DE GAUCHE	2	2	2	2	2	2
39.	10184-K591	SUPPORT - SIDE SHELF - RIGHT	SUPPORT TABLETTE DE DROITE	2	2	2	2	2	2
39.	10956-K401	BRACE - UPPER REAR	SUPPORT ARRIERE	1	1	•	•	•	•
	10956-K501	BRACE - UPPER REAR	SUPPORT ARRIERE	•	•	1	1	1	1

PARTS LIST/LISTE DES PIÈCES

KEY #	ITEM #	DESCRIPTION	DESCRIPTION	941-24	941-44	951-24	951-44	951-74	951-94
				941-27	941-47	951-27	951-47	951-77	951-97
40.	10711-K401	SHELF - LOWER	TABLETTE INFÉRIEURE	1	1	*	*	*	*
	10711-K501	SHELF - LOWER	TABLETTE INFÉRIEURE	*	*	1	1	1	1
46.	S17105	BRACKET - CYLINDER LP	SUPPORT DU RESERVOIR PL	1	1	1	1	1	1
49.	10711-K441	CONDI-BIN	CONDI-BIN	1	1	*	*	*	*
	10711-K541	CONDI-BIN	CONDI-BIN	*	*	1	1	1	1
50.	10711-K551	SHELF - SIDE	PLANCHETTE LATÉRALE	2	1	2	1	2	1
53.	S16142-2	SHELF BOARD - FRONT	PLANCHETTE AVANT	1	1	*	*	*	*
	S16144-2	SHELF BOARD - FRONT	PLANCHETTE AVANT	*	*	1	1	1	1
54.	10088-14	FRONT PANEL	PANNEAU AVANT	1	1	*	*	*	*
	10088-15	FRONT PANEL	PANNEAU AVANT	*	*	1	1	1	1
55.	10184-K631	FRONT PANEL BRACKET	SUPPORT POUR PANNEAU AVANT	2	2	2	2	2	2
56.	10892-17	WHEEL	ROUE	2	2	2	2	*	*
	10892-18	WHEEL	ROUE	*	*	*	*	2	2
	10892-12	CASTOR	ROULETTES	*	*	*	*	2	2
57.	10156-K40	SHIELD	ECRAN	1	1	*	*	*	*
	10156-K55	SHIELD	ECRAN	*	*	1	1	1	1
58.	10184-K60	BRACKET-U-CASTOR	SUPPORT A ROULETTE EN "U"	*	*	*	*	2	2
65.	S13003	BURNER ROTISSERIE	BRULEUR A ROTISS	*	*	*	*	1	1
66.	10339-K901	BRACKET ORIFICE	SUPPORT D'ORIFICE	*	*	*	*	1	1
68.	S21361	SPRING	RESSORT	*	*	*	*	1	1
69.	S21381	SCREW - 12 X 1/2	VIS - 12 X 1/2	*	*	*	*	2	2
75.	10338-143	HANDLE	POIGNEE	2	2	2	2	2	2
76.	10239-5	WASHER - HANDLE	RONDELLE DE LA POIGNEE	2	2	2	2	2	2
77.	S15111	GREASE CUP HOLDER	PORTE CONTENANT A GRAISSE	1	1	1	1	1	1
78.	Y-12652	PLUG	EMBOUT DE JAMBE	2	2	2	2	*	*
80.	Y-11549	BOLT - 1/4:20 X 1-7/8	BOULON - 1/4:20 X 1-7/8	20	20	20	20	20	20
83.	S21141	BOLT - 1/4:20 X 5/8	BOULON - 1/4:20 X 5/8	1	1	1	1	1	1
85.	S21255	WASHER	RONDELLE	1	1	1	1	1	1
86.	Y-12656	PLUG - BUTTON	BOUCHON	2	2	2	2	2	2
87.	Y-11793	NUT - 1/4	ECROU - 1/4	10	10	10	10	10	10
88.	Y-11598	NUT WING - 1/4	ECROU PAPILLON - 1/4	19	19	19	19	19	19
89.	Y-11212	NUT TINNERMAN - 1/4	ECROU TINNERMAN - 1/4	6	6	6	6	6	6
90.	10240-12	BOLT WHEEL - 3/8:16	BOULON ROUE - 3/8:16	*	*	*	*	2	2
91.	Y-11967	BOLT - 3/8:16 X 1-3/4	BOULON - 3/8:16 X 1-3/4	2	2	2	2	2	2
92.	Y-12851	WASHER - 3/8	RONDELLE - 3/8	*	*	*	*	2	2
93.	Y-12852	WASHER - EXT TOOTH	RONDELLE - 3/8	2	2	2	2	4	4
94.	Y-12287	NUT - 3/8	ECROU - 3/8	2	2	2	2	2	2
95.	Y-11595	NUT WING - 3/8	ECROU PAPILLON - 3/8	*	*	*	*	2	2
96.	Y-29305	BOLT 10:24 X 3/8	BOULON 10:24 X 3/8	4	8	4	8	6	8
97.	10240-13	WHEEL BOLT	ROUE BOULON	2	2	2	2	*	*
98.	S21123	SCREW - 8 X 1/2	VIS - 8 X 1/2	20	17	20	17	20	17
99.	Y-12646	SCREW - SHOULDER	VIS	4	4	4	4	4	4
101.	Y-12853	WASHER - #8	RONDELLE - #8	4	4	4	4	4	4
104.	Y-12835	SCREW 6-32 X 1/4	VIS 6-32 X 1/4	8	9	8	9	8	9
105.	Y-29307	NUT - 10:24	ECROU - 10:24	*	7	*	7	*	7
108.	10472-71-2	KNOB	BOUTON	*	1	*	1	*	1
110.	10225-T09	GRID	GRILLE	*	1	*	1	*	1
111.	10390-T10	SIDE BURNER	BRULEUR DE COTE	*	1	*	1	*	1
113.	10342-T08	ELECTRODE - SIDE BURNER	ELECTRODE - BRULEUR DE COTE	*	1	*	1	*	1
114.	10393-T401	COVER - SIDE BURNER	COUVERCLE LATÉRAL	*	1	*	1	*	1
115.	Y-12083	NUT 10:24	ECROU - 10:24	*	2	*	2	*	2
116.	Y-12848	SCREW 10:24 X 1/2	VIS 10:24 X 1/2	*	2	*	2	*	2
117.	10393-K32	SHELF - SIDE BURNER	SUPPORT DE BRULEUR DE COTE	*	1	*	1	*	1
118.	10393-T221	SHIELD - SIDE BURNER	ECRAN DE CUVETTE LATÉRAL	*	1	*	1	*	1