

**7** Items to Assemble  
1 Grill Bottom Assembly  
4 Screws

A Angle grill bottom assembly around and under the rails.  
**CAUTION: Be careful not to dislodge burner tubes.**  
B Make sure the on each side of bottom casting are nested into notches on casting seat.  
C Attach 4 screws inside grill bottom and into casting seat.

Qty: 4

**8** Items to Assemble  
1 Electrode w/Wing Nut or Nut  
2 Screws

A Inside bottom casting, insert electrode and finger tighten with wing nut or nut.

View of electrode attached and aligned with a port hole in the burner.

Front

**9** Items to Assemble  
1 Control Panel  
2 Screws

Loosen long wire and place behind front panel. Do not connect at this time.

A Hold control panel close to front panel and insert ignition wire to electrode.  
B Insert regulator into opening in front panel.  
C Position valves into burner tubes (see burner-valve view). Rotate valves up and rest flange over rail.  
D Attach control panel to leg on each side with 1 screw into top hole.

Qty: 2

Burner Tubes

Correctly assembled burner tube and valve.

**10** Items to Assemble  
1 Shelf  
5 Screws  
1 Fascia

A Shelf slides into rails. Screws with 4 screws.  
B Fascia tabs must insert into 2 slots in front of shelf, then slide towards leg.  
C Fasten fascia with 1 screw into second hole through control panel and leg.

Qty: 5

**11** Items to Assemble  
1 Sideburner Assembly  
4 Screws

A Slide sideburner assembly onto rails. Attach with 4 screws.

Qty: 4

**12** Items to Assemble  
1 Sideburner Burner  
1 Brass Ring  
1 Wing Nut

A Insert sideburner burner into sideburner body. Make sure valve fits into tube before attaching, wing nut. Only one wing nut required.  
B Place brass ring on top of sideburner burner.

Qty: 1

Sideburner tube and valve properly engaged.

**13** Items to Assemble  
1 Fascia  
1 Bracket  
1 Screw, 1/2"  
1 Screw, 3/8"

A Slide fascia around manifold and insert sideburner valve into slot. Fascia tabs must insert into 2 slots in front of shelf, then slide towards leg. Fasten fascia into second hole through control panel and leg.  
B Place base on valve and attach with 3/8" screw.  
C Attach long wire from electronic ignition module to electrode beneath sideburner.

Caution: If there is a plastic sleeve on the sideburner valve, remove it before connecting the long wire.

3/8" screw

**14** Follow these instructions to install Logo Plate, Bezel and Temperature Gauge into Grill Lid (if necessary).

Items to Assemble  
1 Logo Plate  
1 Bezel  
1 Temperature Gauge

A Insert logo plate into grill lid.  
B Center bezel over large hole on grill lid.  
C Insert temperature gauge into hole on bezel and grill lid. Gently press temperature gauge down to engage.  
Note: Do not use excessive force when pushing these pieces on grill lid. This may damage the locking device on the temperature gauge.

Grill Lid

Logo Plate

Back side of Temperature Gauge showing locking device.

**15** Items to Assemble  
1 Handle  
2 Wing Nuts  
2 Spouser Bolts  
5 Control Knobs  
1 Ignitor Button  
1 AAA Battery

A Place handle on the top casting. Attach wing nut to slide.  
B Attach top casting with shoulder bolts.  
C Insert a side of battery into igniter module. Note correct position to hold ignitor button. Push on button once to test ignition.  
D Push button on igniter module and turn right 1/4 turn to lock in place.  
E Place knobs on valve stems.

Bezel

Ignitor Button

Back of button

Turn 1/4

Correct position

**16** Items to Assemble  
4 Vaporizer tents  
2 Piece grates and sideburner grid as shown.  
1 Warming Rack  
1 Sideburner Grid

A Note correct position of vaporizer tents directly over burners.  
B Place grates and sideburner grid as shown.  
C Place warming rack in slots on bottom casting.

Warming rack slots

**17** Items to Assemble  
1 (increased) LP Tank

LP tank is sold separately. Use only with an (over-all protection sleeve) OPR equipped LP tank. Fill and leak check before attaching to grill and regulator.  
Failure to install tank correctly may allow gas flow to be damaged in operation, resulting in the risk of fire.

Please LP tank into hole in bottom sheet. Tighten thumbscrew to hold LP tank securely in place.

See the Use & Care manual to correctly install the LP Tank. Leak Test and do the Burner Flame Check.

Back of cart

**18** Items to Assemble  
1 Grease Tray Assembly  
1 Grease Pan

A Slide grease tray into brackets on bottom casting.  
B Slide grease pan into brackets on grease tray.

CAUTION

Failure to install the grease tray will cause hot grease to drip from bottom of grill with risk of fire or property damage.

You may have hardware left over after completing assembly of your grill. For some cases we have included extra hardware to ensure you have enough.