


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Broil King 942-27 Owner's Manual

[Shop genuine replacement parts for Broil King 942-27](#)



[Find Your Broil King Grill Parts - Select From 1350 Models](#)

----- Manual continues below part list -----

Available Replacement Parts for Broil King 942-27


14625	warming rack universal, 15 x 6.5
119-5000-0	GGK IGNITOR
10472-K36	KNOB GAS VALVE 1 3/4 #E +
18432	INFINITY BURNER T401
10892-8NG	WHEEL 8 INCH GREY WALL
10342-T301	IGNITOR ELECTRODE ASSEMBLY 8 BURNER 1993
10222-T32	GRATE 32/35 18 INCHx11 INCH +
18013	LARGE PROBE HEAT INDICATOR
10184-K581	SHELF SUPPORT LFT BLK
10184-K591	SHELF SUPPORT RH BLK
10184-R19	TANK RETAINER-PEDESTAL-NEW
S15111	GREASE CUP HOLDER ALL P8069A +
10239-7	HANDLE GASKET TRIANGULAR 1/8
30260130	SHELF SIDE REV A +
41650	50-pc briquetts. ***Read ext info***
80012	regulator and hose READ ADD. INFO
CG-10SS	Stainless steel grid 14.5 x 17.25
10111-K45	HOSE 3/8 INCH ASSEMBLY NG 10 FOOT +

Broil King


REDDI-BILT BARBECUES

ASSEMBLY MANUAL & PARTS LIST


MANUAL DE MONTAGE & LISTE DE PIÈCES




Broil King
CROWN 2
942-24
942-27




Broil King
CROWN 4
942-44
942-47




Broil King
REGAL 2
952-24
952-27



Broil King
REGAL 4
952-44
952-47



Broil King
SOVEREIGN 25
952-74
952-77



Broil King
SOVEREIGN 30
952-94
952-97

RETAIN FOR FUTURE REFERENCE




VEUILLEZ CONSERVER POUR REFERENCE ULTERIEURE






ONWARD MULTI-CORP INC. 585 KUMPF DRIVE, WATERLOO, CANADA N2V 1K3




MANUFACTURED BY / FABRIQUES PAR LA

1































3















NORTH AMERICA



PARTS LIST/LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	DESCRIPTION	942-24	942-44	952-24	952-44	952-74	952-94
				942-27	942-47	952-27	952-47	952-77	952-97
1.	10909-T32	CASTING BOTTOM	FOND DU FOYER	1	1	•	•	•	•
	10909-T42	CASTING BOTTOM	FOND DU FOYER	•	•	1	1	1	1
2.	10473-T32	CASTING TOP	COUVERCLE DU GRIL	•	•	•	•	•	•
	10473-T42	CASTING TOP	COUVERCLE DU GRIL	1	1	•	•	•	•
3.	10081-BK321	NAMEPLATE	PLAQUE D'IDENTIFICATION	•	•	1	1	1	1
	10081-BK428	NAMEPLATE	PLAQUE D'IDENTIFICATION	1	1	•	•	•	•
	10081-BK429	NAMEPLATE	PLAQUE D'IDENTIFICATION	•	•	•	1	•	•
5.	10571-5	HEAT INDICATOR	INDICATEUR DE CHALEUR	•	•	•	•	1	1
7.	S21233	HINGE CLIP	ATTACHE DE CHEVILLE	1	1	1	1	1	1
8.	10222-T32	GRATE	GRILL POUR BRIQUETTES	2	2	2	2	2	2
	10222-T42	GRATE	GRILL POUR BRIQUETTES	1	1	•	•	•	•
9.	10225-T326	GRID - CAST IRON	GRILLE	•	•	1	1	1	1
	10225-T426	GRID - CAST IRON	GRILLE	2	2	•	•	•	•
11.	10225-T327	GRID RETRACTABLE	GRILLE RETRACTABLE	•	•	2	2	2	2
	10225-T428	GRID RETRACTABLE	GRILLE RETRACTABLE	1	1	•	•	•	•
14.	10010-45	BRIQUETS - CERAMIC	BRIQUETTES - CERAMIQUE	•	•	1	1	1	1
	10010-55	BRIQUETS - CERAMIC	BRIQUETTES - CERAMIQUE	1	1	•	•	•	•
15.	10390-T401	BURNER ASSY	ENSEMBLE DE BRULEUR	•	•	1	1	1	1
	10390-T501	BURNER ASSY	ENSEMBLE DE BRULEUR	1	1	•	•	•	•
17.	10342-21	IGNITOR	ALLUMEUR	•	•	1	1	1	1
	10342-22	IGNITOR	ALLUMEUR	1	•	•	•	•	•
18.	10342-T301	ELECTRODE	ELECTRODE	•	1	•	1	•	1
21.	10440-K40	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	1	1	1	1	1	1
	10440-K41	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	1	•	•	•	•	•
	10440-K42	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	•	•	•	•	•
	10440-K43	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	1	•	•	•	•
	10440-K50	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	•	1	•	•	•
	10440-K51	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	•	•	•	•	•
	10440-K52	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	•	•	1	•	•
	10440-K53	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	•	•	•	•	•
	10440-K58	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	•	•	•	•	1
	10440-K59	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	•	•	•	•	1
	10440-K62	CONTROL ASSY LP	SOUPAPE, (GAZ PROPANE)	•	•	•	•	1	•
	10440-K63	CONTROL ASSY NG	SOUPAPE, (GAZ NATUREL)	•	•	•	•	•	•
21A.	S10125	HOSE - SIDE BURNER LP	TUYAU DU BRULEUR LATERAL PL	•	1	•	1	•	1
	S10126	HOSE - SIDE BURNER NG	TUYAU DE BRULEUR LATERAL GN	•	•	•	•	•	•
21B.	S10133	HOSE - REARBURNER LP	TUYAU DE BRULEUR ARRIERE PL	•	•	•	1	•	1
	S10139	HOSE - REARBURNER NG	TUYAU DE BRULEUR ARRIERE GN	•	•	•	•	1	•
	S10134	HOSE - REARBURNER LP	TUYAU DE BRULEUR ARRIERE PL	•	•	•	•	•	1
	S10140	HOSE - REARBURNER NG	TUYAU DE BRULEUR ARRIERE GN	•	•	•	•	•	1
22.	10114-17	HOSE & REGULATOR LP - QCC1	TUYAU ET REGULATEUR PL - QCC1	1	1	1	1	1	1
	10111-K47	HOSE NATURAL GAS	TUYAU (GAZ NATUREL)	1	1	1	1	1	1
23.	10472-K36	CONTROL KNOB	BOUTON DE CONTROLE	2	3	2	3	3	4
30.	10086-K401	DECO PLATE	PLAQUE DECORATIVE	1	•	•	•	•	•
	10086-K411	DECO PLATE	PLAQUE DECORATIVE	•	1	•	•	•	•
	10086-K501	DECO PLATE	PLAQUE DECORATIVE	•	•	1	•	•	•
	10086-K511	DECO PLATE	PLAQUE DECORATIVE	•	•	•	1	•	•
	10086-K521	DECO PLATE	PLAQUE DECORATIVE	•	•	•	•	•	1
	10086-K531	DECO PLATE	PLAQUE DECORATIVE	•	•	•	•	1	•
31.	10194-K401	CONTROL COVER	PANNEAU DE CONTROLE	1	1	•	•	•	•
	10194-K501	CONTROL COVER	PANNEAU DE CONTROLE	•	•	1	1	1	1
33.	10338-K571	POST WHEEL	PIEDS DE ROUE	4	4	4	4	4	4
35.	10184-K561	SUPPORT - CASTING - LEFT	SUPPORT GAUCHE DU FOYER	1	1	1	1	1	1
36.	10184-K571	SUPPORT - CASTING - RIGHT	SUPPORT DROIT DU FOYER	1	1	1	1	1	1
37.	10184-K581	SUPPORT - SIDE SHELF - LEFT	SUPPORT TABLETTE DE GAUCHE	2	2	2	2	2	2
38.	10184-K591	SUPPORT - SIDE SHELF - RIGHT	SUPPORT TABLETTE DE DROITE	2	2	2	2	2	2
39.	10956-K401	BRACE - UPPER REAR	SUPPORT ARRIERE	1	1	•	•	•	•
	10956-K501	BRACE - UPPER REAR	SUPPORT ARRIERE	•	•	1	1	1	1

PARTS LIST/LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	DESCRIPTION	942-24	942-44	952-24	952-44	952-74	952-94
				942-27	942-47	952-27	952-47	952-77	952-97
40.	10711-K401	SHELF - LOWER	TABLETTE INFERIEURE	1	1	•	•	•	•
	10711-K501	SHELF - LOWER	TABLETTE INFERIEURE	•	•	1	1	1	1
46.	S17105	BRACKET - CYLINDER LP	SUPPORT DU RESERVOIR PL	1	1	1	1	1	1
49.	10711-K441	CONDI-BIN	CONDI-BIN	1	1	•	•	•	•
	10711-K541	CONDI-BIN	CONDI-BIN	•	•	1	1	1	1
50.	10711-K551	SHELF - SIDE	PLANCHETTE LATERALE	2	1	2	1	2	1
53.	S16142-2	SHELF BOARD - FRONT	PLANCHETTE AVANT	1	1	•	•	•	•
	S16144-2	SHELF BOARD - FRONT	PLANCHETTE AVANT	•	•	1	1	1	1
54.	10088-14	FRONT PANEL	PANNEAU AVANT	1	1	•	•	•	•
	10088-15	FRONT PANEL	PANNEAU AVANT	•	•	1	1	1	1
55.	10184-K631	FRONT PANEL BRACKET	SUPPORT POUR PANNEAU AVANT	2	2	2	2	2	2
56.	10892-18	WHEEL	ROUE	2	2	2	2	2	2
57.	10156-K40	SHIELD	ECRAN	1	1	•	•	•	•
	10156-K55	SHIELD	ECRAN	•	•	1	1	1	1
65.	S13003	BURNER ROTISSERIE	BRULEUR A ROTISS	•	•	•	•	1	1
66.	10339-K901	BRACKET ORIFICE	SUPPORT D'ORIFICE	•	•	•	•	1	1
68.	S21361	SPRING	RESSORT	•	•	•	•	1	1
69.	S21381	SCREW - 12 X 1/2	VIS - 12 X 1/2	•	•	•	•	2	2
74.	Y-6616	BOLT	BOULON	2	2	2	2	2	2
75.	10338-145	HANDLE	POIGNEE	2	2	2	2	2	2
76.	10239-6	WASHER - HANDLE	RONDELLE DE LA POIGNEE	2	2	2	2	2	2
77.	S15111	GREASE CUP HOLDER	PORTE CONTENANT A GRAISSE	1	1	1	1	1	1
78.	10892-12	CASTOR	ROULETTES	2	2	2	2	2	2
80.	Y-11549	BOLT - 1/4:20 X 1-7/8	BOULON - 1/4:20 X 1-7/8	20	20	20	20	20	20
82.	Y12860	SCREW - 1/4:20 X 1"	VIS - 1/4:20 X 1"	4	4	4	4	4	4
83.	S21141	BOLT - 1/4:20 X 5/8	BOULON - 1/4:20 X 5/8	1	1	1	1	1	1
85.	S21255	WASHER	RONDELLE	1	1	1	1	1	1
86.	Y-12656	PLUG - BUTTON	BOUCHON	2	2	2	2	2	2
87.	Y-11793	NUT - 1/4	ECROU - 1/4	10	10	10	10	10	10
	Y-11598	NUT WING - 1/4	ECROU PAPILLON - 1/4	19	19	19	19	19	19
89.	Y-11212	NUT TINNERMAN - 1/4	ECROU TINNERMAN - 1/4	6	6	6	6	6	6
91.	Y-11967	BOLT - 3/8:16 X 1-3/4	BOULON - 3/8:16 X 1-3/4	2	2	2	2	2	2
94.	Y-12287	NUT - 3/8	ECROU - 3/8	2	2	2	2	2	2
96.	Y-29305	BOLT 10:24 X 3/8	BOULON 10:24 X 3/8	4	8	4	8	6	8
97.	10240-13	WHEEL BOLT	ROUE BOULON	2	2	2	2	•	•
98.	S21123	SCREW - 8 X 1/2	VIS - 8 X 1/2	20	17	20	17	20	17
99.	Y-12646	SCREW - SHOULDER	VIS	4	4	4	4	4	4
101.	Y-12853	WASHER - #8	RONDELLE - #8	4	8	4	8	4	8
104	Y- 12835	SCREW 6-32 X 1/4	VIS 6-32 X 1/4	8	8	8	9	8	9
105.	Y-29307	NUT - 10:24	ECROU - 10:24	•	13	•	13	•	13
108.	PB20-60	LID HANDLE	POIGNEE	•	1	•	1	•	1
110.	10225-T10	GRID	GRILLE	•	1	•	1	•	1
111.	10390-T10	SIDE BURNER	BRULEUR DE COTE	•	1	•	1	•	1
113.	10342-T08	ELECTRODE - SIDE BURNER	ELECTRODE - BRULEUR DE COTE	•	1	•	1	•	1
114.	10393-K40	COVER - SIDE BURNER	COUVERCLE LATÉRAL	•	1	•	1	•	1
115.	Y-29305	SCREW 10:24 X 3/8	VIS 10:24 X 3/8	•	4	•	4	•	4
117.	10393-K50	SHELF - SIDE BURNER	SUPPORT DE BRULEUR DE COTE	•	1	•	1	•	1
118.	10393-T221	SHIELD - SIDE BURNER	ECRAN DE CUVETTE LATÉRAL	•	1	•	1	•	1

