


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



GE ZGG36L21CSS Owner's Manual

[Shop genuine replacement parts for GE ZGG36L21CSS](#)



[Find Your GE Grill Parts - Select From 85 Models](#)

----- Manual continues below -----

ZGG36L21CSS » GAS GRILL PARTS

#	Part Number	Description	Qty
1	WB49X5591	TOP GRATE	1
2	WB63X10010	ROLL TOP LID	1
3	WB07X10088	COVER OPEN CORNER R/H	1
5	WB28X10005	ROTISSERIE BURNER	1
8	WB32X10005	AREATION PAN	1
9	WB07X10037	SIDE BURNER COVER	1
10	WB02X8600	VENTURI GASKET	2
13	WB01X10032	PAL NUT	1
18	WB28X10006	HEX BURNER	2
20	WB38X10006	VENTURI LONG	1
21	WB02X10383	BEZEL KNOB	1
23	WB02X10658	HOSE ASSY LP 33"	1
24	WB02X10657	REGULATOR ASSY LP	1
25	WB21X10021	ROTIS ORIFICE HOOD LP	1
26	WB01X10167	ROTIS ORIFICE PLUG LP	1
27	WB21X5368	ORIFICE LP GRL/GRD	1
28	WB02X10459	MANIFOLD	1
29	WB02X10349	MONOGRAM LOGO	1
30	WB03X10014	KNOB SAFETY VALVE	1
31	WB07X10042	VALVE SHIELD	1
32	WB07X10041	BEZEL SAFETY VALVE	1
33	WB02X10381	ORIFICE ELBOW	1
34	WB07X10084	ELECTRODE COVER L/H	1
35	WB01X10017	NUT WITH RETAINER 8-32	1
36	WB36X10020	SIDE BODY PANEL /H	1
36	WB36X10021	SIDE BODY PANEL	1
37	WB07X10101	ROTIS BURNER HSG	1
38	WB02X10380	STAINLESS STEEL TUBING	1
39	WB02X10377	ELECTRODE ASM	1
41	WB28X10007	SMOKER BURNER	1
42	WB02X10370	ROTISSERIE ROD BKT	1
44	WB49X10124	DRIP PAN HANDLE ASM 36	1
47	WB15X10062	COVER HANDLE	2
48	WB02X10382	BRACKET ORIFICE ELBOW	1
49	WB02X10376	AIR SHUTTER	1
50	WB03X10016	KNOB IGNITER ROTARY	1
54	WB02X10372	THERMOCOUPLE	1
55	WB02X10386	CORNER TUBING COVER L/H	1
57	WB07X10047	PROTECTION PLATE	1
58	WB02X10428	ELECTRODE-ROTIS	1
59	WB15X10005	ROTISSERIE HANDLE	1
60	WB21X10015	SMOKER VALVE	1
61	WB01X10018	SHOULDER BOLT	4

#	Part Number	Description	Qty
62	WB02X10665	4 PRONG MEAT HLDR 3/8" D	2
63	WB21X10076	SMOKER ORIFICE HOOD LP	1
64	WB02X10460	ROTISSERIE ROD	1
65	WB03X10013	ROTIS. MOUNT KNOB	1
66	WB02X10374	ROTIS. MOUNT BASE	1
67	WB07X10104	FIREBOX ASM	1
68	WB38X10007	VENTURI SHORT	1
69	WB21X10044	SIDE BURNER ORIFICE LP	1
70	WB02X10659	GRILL ELECTRODE ASSY RH	1
71	WB02X10660	GRILL ELECTRODE ASSY LH	1
72	WB02X10662	BRACKET ANTI-FLIP LEFT	1
73	WB02X10663	BRACKET ANTI-FLIP RIGHT	1
74	WB02X10664	SUPP. ASSY SMOKER TRAY	1
152	WB49X10013	GRILL RACK	1
153	WB28X10021	H BURNER	2
154	WB44X10021	WARMING RACK	1
155	WB21X10014	SAFETY VALVE	1
157	WB02X10385	ROTARY IGNITER	1
160	WB02X10661	GOURMET RADIANTS 36"/48"	2
162	WB21X10013	CONTROL VALVE	1
165	WB03X10015	GRILL KNOB	1
176	WB32X10002	SMOKER BURNER TRAY	1
200	WB07X10102	SERVICE PANEL	1
202	WB07X10043	HEAT SHIELD	1
203	WB07X10039	TOP HEAT SHIELD	1
253	WB49X10023	BURNER BOX	1
300	WB07X10094	LANDING LEDGE	1
301	WB07X10103	VALVE PANEL	1
310	WB15X10014	HANDLE LID	1
311	WB02X10375	HANDLE END CAP SPACER	2
317	WB32X10004	BASTING PAN	1
549	WB26X10014	ROTIS. MOTOR	1
999	49-80009	INSTALLATION INSTRUCTION	1
999	49-8965	USE & CARE MANUAL	1