



Parts List – Model 4636244

No.	Qty.	Description	Part #
A	4	Shelf Nut	400403
B	1	Cooking Grate	112728
C	1	Body/Frame	112868
D	2	Front Shelf Bar	400406
E	2	Front Shelf Bracket	052314
F	1	Side Table	412415
G	2	Wheel	112869
H	1	LP Gas Tank	112870
I	2	Rod	400358
J	1	Tank Support Bracket	052737
K	2	Leg Assembly	052872
L	1	Drip Tray/ASSY Bar	412870
M	1	Manual of Use	112872
N	1	Side Left Table	412710
O	1	Burner Assembly	400367
P	1	Valve/Hose/Regulator	400365
Q	1	Control Panel	400367
R	1	Grill Lid	052367
S	1	Grill Bottom	400363
T	1	Handle	400364
U	1	Ignition Rod	052715
V	2	Control Knob	412403

No.	Qty.	Description	Part #
W	1	Grease Cup	018407
	1	Hardware Bag – Plastic Parts	420308
	1	Hardware Bag – Lid	420315
	1	Hardware Bag – Side Shelves	420306
	1	Hardware Bag – Front Shelf	420307
	1	Hardware Bag – Cart	420313

TRADITIONAL

4636244
ASSEMBLY MANUAL

THIS GRILL IS FOR OUTDOOR USE ONLY

CAUTION: Read and follow all safety statements, assembly instructions, and use and maintenance before attempting to assemble and cook.

INSTALLER/ASSEMBLER: Leave these instructions with consumer.

CONSUMER: Keep this manual for future reference.

⚠ WARNING
Failure to follow all manufacturer's instructions could result in serious personal injury and/or property damage.

⚠ CAUTION
Some parts may contain sharp edges – especially as noted in the manual. Wear protective gloves if necessary.

If you have any questions or need assistance during assembly, please call 1.888.GRILLING.

Visit us on the web at www.charbroil.com

Char-Broil