




























## Parts List - Model 463728504

| Key No. | Description | Part # | Key No. | Description | Part # |
|---|---|---|---|---|---|
| A | 1 | Lower Swinghang | 2 | Control Knob | |
| B | 1 | Cooking Grate | 1 | Bolt Kit | |
| C | 1 | Condiment Basket | 1 | Bolt Kit | |
| D | 1 | Tank Holder | 2 | Tank Retainer Wire | |
| E | 1 | Handle | 16 | Cabinet Screw | |
| F | 1 | Side Shelf | 2 | Legs (Pair) | |
| G | 2 | Wheel Assembly | 12 | Grate Clip | |
| H | 1 | Middle Grate | 20 | Grease Clip | |
| I | 1 | Upper Swinghang | 22 | Leg Extender | |
| J | 1 | 20 lb Gas Tank | 1 | Hardware Bag, Cart | |
| K | 1 | Back Support Brace | 1 | Hardware Bag, Shelf | |
| L | 1 | Axle | 1 | Hardware Bag, Grill | |
| M | 1 | Grill Frame | | | |
| N | 1 | Side Support Brace | | | |
| O | 1 | Tank Support Bracket | | | |
| P | 2 | Leg Assembly | | | |
| Q | 1 | Front Panel | | | |
| R | 1 | Grill Body | | | |
| S | 4 | Wheel 10" T.S.S. Cart/ Top Cover | | | |
| T | 2 | Side Grip | | | |
| U | 1 | Control Panel Assembly | | | |
| V | 1 | Control Panel Assembly | | | |

**Optional Assembly Hardware**
We stock extra customer grade hardware to use tools. Optional hardware must be purchased separately.

**QUICKSET**

463728504
ASSEMBLY MANUAL

**THIS GRILL IS FOR OUTDOOR USE ONLY**

**CAUTION:** Read and follow all safety statements, assembly instructions, and use and care directions before attempting to assemble and use.

**INSTALLER/ASSEMBLER:** Leave these instructions with consumer.

**CONSUMER:** Keep this manual for future reference.

**⚠ WARNING**
Failure to follow all manufacturer's instructions could result in serious personal injury and/or property damage.

**⚠ CAUTION**
Some parts may contain sharp edges - especially as noted in the manual! Wear protective gloves if necessary.

If you have any questions or need assistance during assembly, please call 1-800-241-7846.

Visit us on the web at www.charbroil.com

Char-Broil
RECIPES OF ONE FLAME