





Parts List - Model 46346004

No.	Qty.	Description	Part#	No.	Qty.	Description	Part#
A	1	Bottom Shelf	103911	AA	1	Bottom Burner Tube	103931
B	4	Wheel	103975	AB	1	12" Venturi Tube	103936
C	1	Top Cooking	103934	AC	1	Side Rail	103938
D	1	Bottom Cooking	103935	AD	1	Shelf	103951
E	3	Screws	103955	AE	1	Axle Panel	103965
F	1	Cabinet Door	103970	AF	1	Mounting Bracket	103981
G	1	Handle	103972	AG	1	Crank Axle, small	103982
H	1	Control Knob Assembly	103973	AH	2	Crank Axle, large	103983
I	2	Wheels	103974	AI	1	Valve Access/Plug Lighter Assy	103997
J	1	Axle Rod	103146	AJ	1	Cooking Wood	103151
K	3	Hyperion Tanks	103987	AK	1	Long Wheel	4"/4" 45"
L	1	Screws Tray Assembly	103988	AL	1	Long Assembly Long	103989
M	1	Screws Pan Assembly	103991	AM	1	Long Assembly Short	103990
N	1	Handle, Right	103992	AN	1	Valve Knob Bronze	103999
O	1	Handle, Left	103994	AO	2	4"/4 Nuts	104104
P	2	Leg Bolt Knobs	103995	AP	3	12" Nuts	103106
Q	4	Control Knobs	103997	AQ	3	Cooking Thermometer	103198
R	4	Wheels	103998	AR	1	Ignition Cross, Left	103199
S	1	Endcaps	103999	AS	1	Ignition Cross, Right	103100
T	1	Ignition Button	103101	AT	1	Temperature Gauge	103201
U	1	Rotisserie Frame	103903	AU	1	Temperature Gauge Bezel	4"/4" 98
V	1	24" Ignition Wire	103904	AV	1	Ignition Manifold	103998
W	1	Rotisserie Motor	103 961	AW	1	Match Holder w/Chain	103206
X	1	Rotisserie Left Prong	103 962	AX	1	Rotisserie Front Prong	103198
Y	1	Rotisserie Handle	103963	AY	2	Rotisserie Handle Mount	103971
Z	1	Rotisserie Grill	103964	AZ	1	Hardware Bag	103126