

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Electrolux EL7060A Owner's Manual


[Shop genuine replacement parts for Electrolux
EL7060A](#)



[Find Your Electrolux Vacuum Cleaner Parts - Select From 68 Models](#)

----- Manual continues below -----


Power Head EL13A - EL7060A



Power Head EL13A - EL7060A

Ref #	Part	Description	Comments	Qty
1	NUE-017-6	HOOD ASSEMBLY (ELECTROLUX		
2	63399-1	SCREW PACKAGE		
3	NUE-149-119N	PCB FIX BRACKET		
4	78188-2	HGT ADJ PEDAL & GRAPHICS		
5	78190-2	HANDLE RELEASE & GRAPHICS		
6	NUE-012A	UNIT MAIN PCB ASSEMBLY		
7	NUE-206	INSERT - PEDAL		
8	NUE-408	T-JOINT SEALING FELT		
9	NUE-208	SPRING FOR PIVOT ARM		!
10	NUE-028-1	REAR WHEEL ASSEMBLY		
11	54432-2	PACKAGE - RETAINING RING		
12	16099-3	BASE ASSEMBLY - CARTONED		
13	NUE-010	HEADLIGHT PCB ASSEMBLY		

14	NUE-150-392P	LED FIX COVER		
15	NUE-004-1	FRONT AXLE ASSEMBLY		
16	NUE-407	FILTER WASHER - LOWER		
17	61699-2	BRUSHROLL ASSY - CARTONED		
18	EL097	TRITON UPRIGHT POLY V BELT		
19	NUE-131-625N	SOLE PLATE		
20	63399-2	SCREW PACKAGE		
21	NUE-007	ACTUATOR ASSEMBLY		
22	NUE-011	HEIGHT INDICATOR ASSEMBLY		
23	63399-3	SCREW PACKAGE		
24	NUE-013	OVERLOAD INDICATOR PCB AS		
25	NUE-411	FOAM PAD		
26	NUE-219	SPRING PLATE		
27	NUE-103-119N	AIR CHANNEL COVER		
28	NUE-107-119N	MOTOR COVER		
29	NUE-413	VENT FOAM FOR MOTOR		
30	NUE-006	MOTOR ASSEMBLY		
31	NUE-003A	COUPLING ASSEMBLY		
	NUE-109-625N	C-CLAMP		
	EL13A			




Canister - EL7060A

Ref #	Part	Description	Comments	Qty
1	1181923-07	COVER - COVER		
! 2	1181922-03	HANDLE		
3	2197005-02	DISPLAY L3/L4		

4	1181965-01	SHAFT - PEDAL		
5	2197091-03	PEDALSET COMPLETE		
6	11819! 31-01	LEVER - SWITCH		
7	1181961-07	HINGE - REARCOVER LEFT		
8	1181962-07	HINGE - REARCOVER RIGHT		
9	63157-14	SPRING PACKAGE		
10	2194092-05	COVER - REAR		
11	63157	SPRING PACKAGE		
12	1181974-03	PCB DISPLAY L4		
13	2197055-02	PCB SAT PEDAL ACT		
14	1181974-03	PCB DISPLAY L4		
15	1181868-01	PCB POWER MODULE ONE INT		
16	1181955-01	SEAL		
17	1181954-01	SEAL		
18	2197012-01	MOTOR FILTER ASSEMBLY		
19	1181926-04	HOLDER - DISASTER FILTER		
20	2197016-21	COVER - DUSTBAG		
21	1181952-01	CONNECTOR - CONTACT		
22	1181940-01	HOSE CONNECTOR		
23	1181959-03	POWER OUTLET L3		
24	1181912-03	CATCH - FRONT LID		
25	63147	SPRING PACKAGE		
26	1130914-03	SAFETY - DEVIVR		
27	1181943-07	LID - FRONT		
28	1181905-01	HOLDER - DUSTBAG		
29	1096847-03	DUST BAG GASKET		
30	1181901-01	DUSTBAG - CONTAINER		
31	2194097-01	FRAME - RIGHT SIDE		
32	1181929-01	COVER - RIGHT SIDE		
33	1181916-01	RING - SUSPENSION		!
34	2192664-01	SUSPENSION BLOCK - MOTOR		
35	1181918-01	COVER - LEFT SIDE		
36	2198345-66	CORD REEL ASSEMBLY		
37	1096042-07	HOLDER - FRONT WHEEL		
38	6680981-64	FRONT WHEEL POM/TF V2		
39	1181988-01	WHEEL - REAR		
40	1181960-08	RECESS - CABLE		
41	2197019-08	BOTTOM ASSEMBLY		
42	1181938-01	SEALING - MOTORHOUSE		
43	1181903-01	COVER - MOTOR		
44	1129020-01	SOUND FOAM (MOTOR)		
45	1130969-07	TCO/MOTOR WIRE ASSEMBLY		
46	63160	MOTOR ASSY - PACKAGED		
47	1181917-01	BELLOW		
48	1181935-08	COVER - GRILL		
49	1181987-07	BUTTON - GRILL COVER RIGH		< /td>
50	1181986-07	BUTTON - GRILL COVER LEFT		
51	1181953-01	SOUND ABSORBER - FILTER G		

52	1181919-01	SOUND ABSORBER - FILTER G		
53	1181911-03	FRAME - FILTER GRILL		
54	2192645-03	SEAL - FILTER		
55	EL012W	WASHABLE HEP A FILTER		
56	1181939-01	SEALING - GRILLCOVER		
57	1181971-02	PCB SAT DB/FI L4		
58	1181870-03	PCB POWER SUPPLY		
59	1181928-01	COVER - LEFT SIDE		
60	2194096-01	FRAME - LEFT SIDE		



Ref #	Part	Description	Comments	Qty
1	2193714-01	MULTI TOOL 2G		
2				
3	2193708-01	NOZZLE PRENO 2G ELX GNGRY		
4	1181611-01	SEAL - TUBE		
5	2197098-02	TUBE TElesc SUMO UL AC NU		
6	E-EL202F	ELCTRLX SYNTHTC S BAG CLA		
7	61054-14	SWIVEL HOSE ASSY - CARTON		
	1131408-52	NOZZLE - FURNITURE		
	79102	OWNERS GUIDE		
	1181806-01	MULTI TOOL CLIP 2G		