

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



LASKO 1120 Owner's Manual

[Shop genuine replacement parts for LASKO 1120](#)



[Find Your LASKO Humidifier Parts - Select From 20 Models](#)

----- Manual continues below -----

LIMITED WARRANTY

SHOULD ACCESSORY PARTS BE NEEDED, CONTACT THE MANUFACTURER FOR IN-WARRANTY REPLACEMENT PARTS. A COPY OF PROOF-OF-PURCHASE MUST BE INCLUDED ALONG WITH THE TYPE AND STYLE, WHICH IS LOCATED ON THE BOTTOM OF YOUR APPLIANCE.

This product is warranted for one year from the date of original purchase against defects in workmanship and/or materials. At our option, parts that prove to be defective will either be repaired or replaced or the whole product will be replaced. Should electrical or mechanical repair become necessary during the warranty period, send your complete product, postage or freight prepaid to the nearest service center. Call the number below for the service station nearest you.

Should a part need replacement, you must give us the type and style of your appliance. You will find this at the bottom of the appliance. In either case, a copy of your proof of purchase is requested.

This warranty does not apply if the damage occurs because of accident, improper handling or operation, shipping damage, abuse, misuse, unauthorized repairs made or attempted, or the use of the product for commercial service.

ALL WARRANTIES, EXPRESSED OR IMPLIED, LAST FOR ONE YEAR FROM THE DATE OF ORIGINAL PURCHASE. THIS WARRANTY DOES NOT COVER LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR ANY CAUSE WHATSOEVER.

Some states do not allow limitations on how long any implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so that the above limitations and exclusions may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

FOR PARTS AND TO ORDER REPLACEMENT FILTERS:

For Replacement Parts or Filters please call: **1-800-966-2028. MONDAY THROUGH FRIDAY, BETWEEN THE HOURS OF 8 AM AND 4 PM EST. "PLEASE DO NOT RETURN PRODUCT TO PLACE OF PURCHASE."** Reference model number **1120** when you call.


FOR TECHNICAL ASSISTANCE and SERVICE CENTER LOCATIONS:

For any questions, comments or the location of your nearest service center, **PLEASE CALL OUR TOLL-FREE "HOTLINE" AT 1-800-233-0268. MONDAY THROUGH FRIDAY, BETWEEN THE HOURS OF 8 AM AND 5 PM EST.** Please reference product name and model number when you call.

Appliance Service Dept. • 300 Confederate Drive Franklin, TN 37065-0569
PLEASE DO NOT SEND PRODUCT TO THIS LOCATION!

NOTES

- Use the convenient Carrying Handle found on the bottom of the Water Tank to bring it to a faucet. Remove the Tank Cap by turning it counterclockwise. Fill the Water Tank with cool tap water. Never use hot water. Replace the Tank Cap by turning clockwise, until tightened. Do not over tighten. (Figure 1)



NOTE: While carrying filled Water Tank back to Humidifier, hold Handle with one hand, while supporting bottom of Water Tank with other hand.

- Place the Water Tank securely on the Base. If positioned properly, water will slowly pour into Base and automatically stop when reaching desired amount.
- Even though your Humidifier will produce approximately 4.0 gallons in a 24 hour period*, the water capacity (amount of water the Humidifier will hold at one time) is 2.0 gallons.

NOTE: Do not move or tilt the Humidifier while filled Water Tank is on Base. To move Humidifier, remove Water Tank and carefully move the rest of Unit to desired location. Replace Water Tank and restart Humidifier.

CAUTION: Do not pour water through the Exhaust Grill on the Upper Housing. Doing so may cause damage and personal injury.



OPERATION INSTRUCTIONS

CAUTION: Always place Humidifier on a firm and level surface. Locate the Power Cord so the Humidifier is not resting on it, and is away from room traffic.

Always carry filled Water Tank separate from rest of Humidifier. Never move water filled Humidifier while plugged in.

- Take extra care to prevent water spillage that may damage furniture or flooring. **The manufacturer will not accept responsibility for damage to property caused by water spillage.**
- Always be sure that the Power Control Knob is in the OFF position when plugging Humidifier into a polarized 120 volt AC wall outlet.

CAUTION: Do not plug Humidifier into electrical outlet with wet hands, or electrical shock may occur.

- Set the Humidistat Control Knob to HIGH.
- Turn the Power Control Knob to the HIGH position.


The Red Power Light should be on. After your Humidifier has been running on HIGH for a few minutes, you may then turn the Power Control Knob to your desired setting.

HIGH Speed: for fast humidification of a large room. This setting will provide approximately 4 gallons of moisture output in a 24 hour period.

MEDIUM Speed: for normal operation.

LOW Speed: for quiet night time operation. (Figure 2)

* Calculations based on ambient conditions of 70° F and 30% relative humidity in a room of average insulation.




CLEANING and FILTER CARE

- Regular cleaning is necessary to ensure proper and efficient operation. The frequency of cleaning depends on the amount of impurities which may be found in the water or how often the Humidifier is in operation. **In either instance, it is recommended that the Humidifier be cleaned at least once a week.**

CAUTION: To prevent electric shock, always turn Power Control Knob to OFF position and unplug before cleaning.

- To replace the Evaporative Filter Pad, remove Rear Grill from the Base by squeezing the Upper Tabs inward and lift out. Remove used Filters and discard. (Figure 3)



- Slide the Water Distribution Tray out. Clean thoroughly and inspect Water Drip Holes for any blockage. Replace Tray to its original position. (Figure 4)

