

LIMITED WARRANTY

SHOULD ACCESSORY PARTS BE NEEDED, CONTACT THE MANUFACTURER FOR IN-WARRANTY REPLACEMENT PARTS. A COPY OF PROOF-OF-PURCHASE MUST BE INCLUDED ALONG WITH THE TYPE AND STYLE, WHICH IS LOCATED ON THE BOTTOM OF YOUR APPLIANCE.

This product is warranted for one year from the date of original purchase against defects in workmanship and/or materials. At our option, parts that prove to be defective will either be repaired or replaced or the whole product will be replaced. Should electrical or mechanical repair become necessary during the warranty period, send your complete product, postage or freight prepaid to the nearest service center. Call the number below for the service station nearest you.

Should a part need replacement, you must give us the type and style of your appliance. You will find this at the bottom of the appliance. In either case, a copy of your proof of purchase is requested.

This warranty does not apply if the damage occurs because of accident, improper handling or operation, shipping damage, abuse, misuse, unauthorized repairs made or attempted, or the use of the product for commercial service.

ALL WARRANTIES, EXPRESSED OR IMPLIED, LAST FOR ONE YEAR FROM THE DATE OF ORIGINAL PURCHASE. THIS WARRANTY DOES NOT COVER LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR ANY CAUSE WHATSOEVER.

Some states do not allow limitations on how long any implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so that the above limitations and exclusions may not apply to you. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

FOR PARTS AND TO ORDER REPLACEMENT FILTERS:

For Replacement Parts or Filters please call: **1-800-966-2028. MONDAY THROUGH FRIDAY, BETWEEN THE HOURS OF 8 AM AND 4 PM EST. "PLEASE DO NOT RETURN PRODUCT TO PLACE OF PURCHASE."** Reference model number **1120** when you call.

FOR TECHNICAL ASSISTANCE and SERVICE CENTER LOCATIONS:

For any questions, comments or the location of your nearest service center, **PLEASE CALL OUR TOLL-FREE "HOTLINE" AT 1-800-233-0268. MONDAY THROUGH FRIDAY, BETWEEN THE HOURS OF 8 AM AND 5 PM EST.** Please reference product name and model number when you call.


Appliance Service Dept. • 300 Confederate Drive Franklin, TN 37065-0569
PLEASE DO NOT SEND PRODUCT TO THIS LOCATION!

NOTES

LASKO
Innovators in Home Comfort

EVAPORATIVE HIGH PERFORMANCE RECIRCULATING HUMIDIFIER

Model 1120



IMPORTANT SAFETY INSTRUCTIONS READ AND SAVE THESE INSTRUCTIONS

Congratulations on your purchase of the Recirculating Humidifier. Featuring the unique use of pump driven water circulation, this unit provides exclusive features that no other humidifiers offer.

IMPORTANT INFORMATION and FEATURES

Your Recirculating Humidifier is an **EVAPORATIVE TYPE HUMIDIFIER**. This means that the air being drawn through the moistened filter naturally evaporates the water and disperses **INVISIBLE MOISTURE** into the air. This type of humidifier **DOES NOT PRODUCE MIST, WATER DROPLETS, STEAM OR EXCESSIVE CONDENSATION** associated with other types of humidifiers.

EXCESSIVE HUMIDITY CAN OFTEN LEAD TO UNANTICIPATED PROBLEMS. Air containing water droplets or mist can create a good habitat for the growth of mold and mildew.

Misting units often oversaturate the air, while the Lasko Recirculating Humidifier reaches a maximum humidity output level without oversaturating. With a properly operating Evaporative Humidifier, the evaporation rate increases naturally when the air is dry. When the humidity in your home is high, moisture output automatically decreases to help prevent damaging condensation.

The Watershow Viewing Window and Water Tank provide a visible way for you to know that your Recirculating Humidifier is operating. As air passes over the Filters, the humidity in the room will increase, and the water level in the Unit will begin to decrease.

Unlike misting humidifiers, the Evaporative Filters in your Recirculating Humidifier also trap unwanted minerals that reside in normal tap water. This filtering also assures there is **NO WHITE DUST** dispersed into the air.

NOTE: A few droplets of water may be present in your Humidifier as a result of our quality testing prior to packaging and shipment.

IMPORTANT SAFETY INSTRUCTIONS


When using electrical appliances, especially where children are present, basic precautions should always be followed in order to reduce the risk of fire, electric shock and injury to persons... Including the following:

1. To prevent possible electrical shock, always turn Humidifier off and unplug before filling, servicing or moving.
2. Always place Humidifier on a stable, flat, level surface. Locate Power Cord so the Humidifier or other objects are not resting on it. Keep the Cord away from room traffic.
3. Do not place Humidifier near a heat source such as stoves, radiators or heaters.
4. This appliance is equipped with a polarized plug (one blade is wider than the other). To reduce the risk of electrical shock, this plug is designed to fit in a polarized outlet only one way. If plug does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
5. Never tilt or attempt to move the Humidifier while it is operating.
6. Always direct air flow away from walls or furniture as excessive moisture may cause damage.
7. Humidifiers require regular cleaning to maintain proper operating conditions. Refer to **Cleaning Instructions** for proper cleaning procedures.
8. Do not place Humidifier on an electrical appliance.

FILLING and REFILLING

1. It is recommended that all Humidifiers be cleaned prior to use. Please read **Cleaning Instructions** for Base and Water Tank cleaning.

- Use the convenient Carrying Handle found on the bottom of the Water Tank to bring it to a faucet. Remove the Tank Cap by turning it counterclockwise. Fill the Water Tank with cool tap water. Never use hot water. Replace the Tank Cap by turning clockwise, until tightened. Do not over tighten. (Figure 1)




NOTE: While carrying filled Water Tank back to Humidifier, hold Handle with one hand, while supporting bottom of Water Tank with other hand.

- Place the Water Tank securely on the Base. If positioned properly, water will slowly pour into Base and automatically stop when reaching desired amount.
- Even though your Humidifier will produce approximately 4.0 gallons in a 24 hour period*, the water capacity (amount of water the Humidifier will hold at one time) is 2.0 gallons.

NOTE: Do not move or tilt the Humidifier while filled Water Tank is on Base. To move Humidifier, remove Water Tank and carefully move the rest of Unit to desired location. Replace Water Tank and restart Humidifier.

CAUTION: Do not pour water through the Exhaust Grill on the Upper Housing. Doing so may cause damage and personal injury.



OPERATION INSTRUCTIONS

CAUTION: Always place Humidifier on a firm and level surface. Locate the Power Cord so the Humidifier is not resting on it, and is away from room traffic.

Always carry filled Water Tank separate from rest of Humidifier. Never move water filled Humidifier while plugged in.

- Take extra care to prevent water spillage that may damage furniture or flooring. **The manufacturer will not accept responsibility for damage to property caused by water spillage.**
- Always be sure that the Power Control Knob is in the OFF position when plugging Humidifier into a polarized 120 volt AC wall outlet.

CAUTION: Do not plug Humidifier into electrical outlet with wet hands, or electrical shock may occur.

- Set the Humidistat Control Knob to HIGH.
- Turn the Power Control Knob to the HIGH position.


The Red Power Light should be on. After your Humidifier has been running on HIGH for a few minutes, you may then turn the Power Control Knob to your desired setting.

HIGH Speed: for fast humidification of a large room. This setting will provide approximately 4 gallons of moisture output in a 24 hour period.

MEDIUM Speed: for normal operation.

LOW Speed: for quiet night time operation. (Figure 2)

* Calculations based on ambient conditions of 70° F and 30% relative humidity in a room of average insulation.




CLEANING and FILTER CARE


- Regular cleaning is necessary to ensure proper and efficient operation. The frequency of cleaning depends on the amount of impurities which may be found in the water or how often the Humidifier is in operation. **In either instance, it is recommended that the Humidifier be cleaned at least once a week.**

CAUTION: To prevent electric shock, always turn Power Control Knob to OFF position and unplug before cleaning.

- To replace the Evaporative Filter Pad, remove Rear Grill from the Base by squeezing the Upper Tabs and lift out. Remove used Filters and discard. (Figure 3)




- Slide the Water Distribution Tray out. Clean thoroughly and inspect Water Drip Holes for any blockage. Replace Tray to its original position. (Figure 4)




CLEANING and FILTER CARE (Continued)


- Insert two new Filter Pads by pressing them onto the Filter Support Pins found on inside of Rear Cover. Filter Pads must be inserted with colored mark on top. (Figure 5)



- Reinstall Rear Grill by engaging three Bottom Tabs on the Grill into inside Rear Grill Cover Wall. Squeeze Top Finger Tabs inward until they slide into the Slots in Top of Rear Grill Cover Wall. (Figure 6)



- To replace the blue Foam Water Filter Disk, remove Water Tank, then Humidifier Body Assembly from the Base. Remove the Disk and discard. (Figure 7)



- Rinse Base thoroughly. Place **Only One** New Foam Water Disk into Base Well. Reattach the Humidifier Body Assembly and Water Tank to the Base.

- To increase the life of your Filter Pads, remove Rear Grill and turn Filters around (so outside of Filter is now facing towards inside of Humidifier). Filter life may be extended by cleaning the Filter in a 20% vinegar solution. To clean Filter, mix one part undiluted vinegar with four parts warm tap water. Soak the Filter in this solution for 20 minutes, rinse Filter thoroughly with warm water to remove vinegar odor.

DO NOT FLATTEN, SQUEEZE OR TWIST FILTER WHEN CLEANING

- Discoloration of the Evaporative Pad is normal after extended use. The discoloration is caused by mineral deposits in the water, and the degree of discoloration will vary depending upon the amount of mineral content in the water. When the Filter surface area is thoroughly discolored, or you notice reduced water usage, it is a good indicator that the Filter Pads need to be replaced. **The Evaporative Pads should be replaced at least once every season.**

The Replacement Filters to be used in this unit are: The Lasko Replacement Evaporative Pad Model THF 11 (Available separately)

Model 1120 requires two Replacement Filter Sets.

- TO REMOVE SCALES** from inside of Base use undiluted white vinegar. Let vinegar stand in Base for 20 minutes then wipe away any scale buildup using a soft brush or cloth. **Do not use soap or detergents and never use an abrasive cleaner.**
- TO DISINFECT TANK AND BASE:** Fill Tank with 1 teaspoon of chlorine bleach and 1 gallon of water. Place Tank back on Base and let stand for 20 minutes. Carefully empty Base and Tank after 20 minutes and rinse well with water until bleach smell is gone. Do not operate Humidifier when there is still cleaner in the water.
- Commercial "Descalers" and "Bacteriostats" are available at your local home improvement center.
- Do not operate Humidifier when there is still cleaner in the water.

OFF SEASON STORAGE

- Clean and dry Humidifier thoroughly per the Cleaning Instructions. **Do not leave any water in the Unit while storing.**
- Dispose of the Evaporative Pad. Do not store a used Evaporative Pad in the Humidifier.
- Place Humidifier back in its carton and store in a cool dry place.