

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



GENERAL AC-1 Owner's Manual

[Shop genuine replacement parts for GENERAL AC-1](#)



[Find Your GENERAL Air Cleaner Parts - Select From 69 Models](#)

----- Manual continues below -----

AC-1

HIGH EFFICIENCY AIR CLEANER

FOR INSTALLATION IN THE RETURN AIR DUCT OF ANY FORCED AIR HEATING AND COOLING SYSTEM



This air cleaner is designed for use in systems up to 2000 CFM. For higher airflows additional units in parallel typical installations are shown below. Choose the appropriate method for each installation.

IMPORTANT: A 26 inch clearance must be allowed for removal of the media frame assembly from the cabinet.

1. Remove two thumb screws from front of cabinet and remove front cover.
2. Slide media frame assembly from air cleaner cabinet.
3. Turn off electricity to furnace.
4. Remove and discard existing furnace air filter.
5. Install air cleaner cabinet in return air system. Be sure to follow airflow direction arrows on interior of cabinet.
6. Install a duct support from the floor if necessary. Duct transitions or turning vanes are recommended for all installations.
7. Tape all joints in duct work between air cleaner and blower compartment.
8. Slide the media frame into the air cleaner cabinet. Be sure the airflow arrow on the media frame is in the same direction as the arrow in the cabinet. The plastic pleat spacers are always on the downstream side of the media frame. The pleat spacers are on the cover and thumb screws.
9. If a condition indicator is to be used, install on a vertical duct surface between the air cleaner and the furnace.
10. Turn on furnace and check performance of all equipment.

INSTALLER: PLEASE FILL OUT AND MAIL GUARANTEE CARD AFTER INSTALLATION IS COMPLETE. MAINTENANCE CARD AND INSTALLATION INSTRUCTIONS WITH HOME OWNER.

Typical Installations

